

Maintenance & Care Instructions



Product

AF002 - Ball Wall

v1

**These are maintenance considerations for this product only and do not contribute towards a formal inspection of any kind.*

Check

Details

Wear and Tear

This product has been designed to be rugged and take the knocks and bumps that playground life will inflict upon it. Despite this, timber is a natural material and must be monitored for delaminating, cracking and splintering over time. Extreme temperature changes and moisture levels will cause timber to expand and contract and over time this can cause fixings to work loose. We advise that you monitor for loose fixings regularly and tighten them where needed.

The impact of hard balls on a timber surface over time can cause timber to wear and produce splinters. We advise that you use soft or leather balls when possible. If you do notice any splintering these patches can be sanded out using a course sand paper followed by a finer grade paper.

Cleaning

With heavy use timber can become dirty in appearance. There are a lot of options available for cleaning timber but the safest and easiest is to clean it with a jet wash on a medium pressure setting.

Vandalism or Damage

If you find that this product has been vandalised or damaged then please ensure its use is restricted immediately. Please contact a member of our team to discuss a safe course of action in order to get your equipment back in action.